

**TO VERIFY THE FIRMWARE ON STANDARD CONSOLES**

1. Pedal the machine to activate the console.
2. Simultaneously press and hold **Program Workout plus and minus (+/-)** for three seconds. The firmware version is displayed under Distance.



3. Press **Pause Clear** twice to exit.

