


VERIFY THE FIRMWARE AND MIDDLE BOARD VERSIONS ON SMART CONSOLES

The firmware version for the smart console is located in the upper right hand corner on the home screen.



The middle board version for the smart console is located in the machine diagnostics screen.

1. Tap the Octane logo (or top outer corners) on the home screen in the following pattern: **O (left), E (right), E (right), O (left)**.



2. Type **922** and then press **Enter**.




3. Press the **Identification** tab and the **Middle Board Version** is displayed.

Machine Diagnostics		
Identification	Model	xxxxxx
Machine Status	Middle Board Version	##-dc
Manual Tests	Radio Version	###
Auto Tests	PAC Model	#
	PAC Version	##
	PAC Brake Version	##

If your Middle Board Version is 2.11 or lower, contact customer service before updating your smart console firmware.

If your Middle Board Version is higher than 2.11, you can update your smart console firmware.

4. Press **Exit** to return to the home screen.





Questions? Contact Octane Fitness Global Support

USA/CANADA

1-888-975-1376

customerservice@octanefitness.com

Octane Fitness Headquarters
7601 Northland Drive North, Suite 100
Brooklyn Park, MN 55428

EUROPE/MIDDLE EAST/AFRICA

31-10-2662412

EMEAService@octanefitness.com

Octane Fitness International Headquarters
Rivium Westlaan 19
2909 LD, Capelle a/d IJssel
The Netherlands

UNITED KINGDOM

0800 088 5540

UKService@octanefitness.com

Octane Fitness UK Ltd.
Friary Court 1321
High Street
Guilford GU1 3DL
United Kingdom

LATIN AMERICA

001-763-757-2662

LAService@octanefitness.com

ASIA PACIFIC

31-10-2662412

APService@octanefitness.com